


- NL** Onderdelen
FR Pièces détachées
EN Spare parts
ES Despiece



NO.	Description	QTY
1	Funnel Assembly	1
2	Drain Tube	1
3	4" Nipple	1
4	Knob	1
5	Hex. Bush	1
6	Pressure Gauge	1
7	Ball Valve	1
8	Tube Connector	1
9	Regulator	1
10	Handle	1
11	Bleeding Valve	1
12	Screw	3
13	Loop Clamp	1
14	Hose/Nozzle Assembly	1
15	Tank Assembly	1
16	Loop Clamp	2
17	"Barbed" Fitting	1
18	Nut	2
19	Washer	2
20	Caster	2
21	Wheel	2
22	Washer	4
23	Retaining Ring	2
24	Screw Plug	1