

- NL** Onderdelen
- FR** Pièces détachées
- EN** Spare parts
- ES** Despiece

PART NO.	DESC.	QTY
1	Oil suction tip	1
2	Measuring cup assembly	1
3	Oil tray	1
4	O-ring	2
5	oil tray's connector	1
6	O-ring	2
7	oil tray's connector	1
8	Hex nut	1
9	1" Ball valve	1
10	Upper connector of drain tube	1
11	Hex nut	2
12	Fixing ring	1
13	Inlay screw	1
14	Clipper	1
15	O-ring	1
16	Drain tube	1
17	Tool tray	1
18	Bush for oil suction tip	1
19	Self-tapping nut	1
20	Rivet	1
21	1" elbow	1
22	Oil intake connector	1
23	Clipper	2
24	Pressure Hose	1
25	Down connector	1
26	Tank	1
27	1/8" safety valve	1
28	Air intake connector	1
29	Air intake pipe connector	1
30	1/4" ball valve	3
31	Quick coupler	1
32	Handle	1
33	Hex nut	1
34	Pipe Clipper	1
35	Hex nut	2
36	Clipper	2
37	Oil discharging connector	1
38	1/2" Ball valve	1
39	Oil discharging pipe connector	1
40	Reinforced nylon hose	1

41	Oil discharging elbow	1
42	Right angle connector	2
43	Flexible hose connector	2
44	Oil lever	1
45	Clipper	2
46	Cap screw	2
47	Washer	2
48	3" Caster	2
49	O-ring	1
50	Drain plug	1
51	circlip	2
52	5" wheel	2

DIAGRAM

